


## Battery Installation and Instructions

1. Using a Phillips head (+) screwdriver, remove the battery compartment cover carefully (see Figure 3).
2. Insert a fresh 9-volt battery (006p, VS332, or equal, NOT SUPPLIED) into the battery compartment and snap the (+) and (-) terminals to the unit's battery clip.
3. Do not try to reverse the terminals. The battery will only fit one way.

- Do not mix old and new batteries.
- Non-rechargeable batteries are not to be recharged.
- Do not use rechargeable batteries.
- Do not mix different types of batteries: alkaline, standard (carbon zinc), or rechargeable batteries.
- Only batteries of the same or equivalent type are to be used.
- Remove exhausted batteries from the unit.
- The supply terminals are not to be short-circuited.
- To prevent corrosion and possible damage to the product, it is recommended to remove the battery from the unit if it will not be used for more than two weeks.



(Figure 3)

4. Replace the battery compartment cover and tighten the screw.  
Do not over tighten.

# GEO SAFARI® Sonic Sleuth

Powerful Hand-Held Listening Device



## User's Guide

**WARNING:**  
CHOKING HAZARD—Small parts.  
Not for children under three (3) years.

Developed in Southern California by Educational Insights.  
© Educational Insights, Inc., Gardena, CA (U.S.A.). All rights reserved. Learning Resources Ltd., King's Lynn, Norfolk (U.K.). Please retain this information.  
Made in China.  
[www.EducationalInsights.com](http://www.EducationalInsights.com)

Fabriqu  en Chine. Informations   conserver.  
Made in China. Bitte bewahren Sie unsere  
Hecho en China. Adresse f r sp tere Nachfragen auf.  
Conserver estos datos.



RISQUE D' TOUFFEMENT: Petites pi ces.  
Si tenid que enlutar en dispositivos de 3 a os.  
ERSTICKUNGSGEFAHR, kleine Teile. Nicht geeignet  
f r Kinder unter 3 Jahren.  
PELIGRO. No conveniente para ni os menores de 3 a os por  
ser susceptible de producir piezas peque as que pueden ser ingeridas.



The Sonic Sleuth is a powerful and versatile hand-held listening device that tunes into sounds from over 300 feet away! It is ideal for studying birds and other wildlife as well as listening in on your friends.


## Let's Look at Your Sonic Sleuth



(Figure 1)

## Assembly

1. Carefully remove all the components from the box.
2. Orient the parabolic dish so that the two support stands are on the bottom and the viewer hole is at the top of the dish.
3. Attach the dish to the front of the Sonic Sleuth by squeezing gently on the two tabs at the front of the unit and pushing the dish over the two locking tabs (see Figure 1).
4. Insert a fresh 9-volt battery into the battery compartment following the instructions on the back of this guide.



(Figure 2)

## Using the Listening Function

1. Plug the headphone into the headphone jack (see Figure 2).
2. Aim the unit at the desired subject.
3. Squeeze the ON/OFF switch to hear amplified sounds.

### **WARNING!**

Do not aim your Sonic Sleuth at the sun, or anywhere near the sun! Instant and irreversible eye damage can occur, including blindness. Adult supervision is strongly recommended when children are using this unit.

## The Frequency Controller

When you are listening to amplified sounds, unwanted background noises like the rumble of traffic can be distracting. The Frequency Controller can reduce these unwanted sounds. While listening, simply turn the Frequency Controller dial until you achieve the desired noise reduction.